

L.E.T. Automotive N.V.
Vaartlaan 20
B-9800 Deinze
TEL: +32(0)9 381 87 87
FAX: -
EMAIL: info@let.be
WEB: WWW.LET.BE



Headlamp aiming systems
Driver assistance sensor aiming
Vision applications

LET-Project number	IDE190007
Project description	Luminoscope system LVC1050-APS-TM
Manufacturer	L.E.T. Automotive N.V. Vaartlaan 20 B-9800 Deinze
Project number	IDE190007
Responsible for project	Andy De Schrijver

Customer	DNH Manufacturing (Pty) Ltd 77 Mangold Street, Newton Park Port Elizabeth 6045 South Africa
Drawing number	IDE190007

Installation	Luminoscope headlamp aiming system	Supply from cabinet	-
Type	LVC1050-APS-TM (PLM-TM)	Main power supply	1~230VAC+PE
Location	Nissan South Africa	Frefuence / Net	60Hz /16A
Quantity	1	Control voltage	24Vdc
		SPS/PLC System	-
		Year of construction	2019

Created on	19/06/2019	2.7.3	
Edit date	1/07/2019	LET	Number of pages 145

[illegible]

Table of contents

Page	Page description	Date	Edited by
+INF/1	Information INF: Title page	19/06/2019	LET
+INF/2	Information INF: Revision history	19/06/2019	LET
+INF/3	Information INF: Table of contents	1/07/2019	LET
+INF/3.a	Information INF: Table of contents	1/07/2019	LET
+INF/3.b	Information INF: Table of contents	20/06/2019	LET
+INF/3.c	Information INF: Table of contents	20/06/2019	LET
+INF/3.d	Information INF: Table of contents	1/07/2019	LET
+INF/4	Information INF: Structural function & location overview	20/06/2019	LET
+INF/5	Information INF: Explanation identification systems	19/06/2019	LET
+INF/6	Information INF: Marking & labeling	19/06/2019	LET
+INF/7	Information INF: Explanation wire colors & color abbreviations	19/06/2019	LET
+INF/8	Information INF: Explanation terminal sizes	19/06/2019	LET
+INF/9	Information INF: Explanation BMK/Component identification	19/06/2019	LET
+INF/10	Information INF: Explanation BMK/Component identification - Add ons	19/06/2019	LET
+INF/11	Information INF: Block schematic overview 1/2	20/06/2019	LET
+INF/12	Information INF: Block schematic overview 2/2	20/06/2019	LET
+GRAPH/1	Graphical pages GRAPH: General installation overview	19/06/2019	LET
+GRAPH/2	Graphical pages GRAPH: Overview Luminoscope system (1/4): General overview	1/07/2019	LET
+GRAPH/3	Graphical pages GRAPH: Overview Luminoscope system (2/4): Details controlbox & signaltower	1/07/2019	LET
+GRAPH/4	Graphical pages GRAPH: Overview Luminoscope system (3/4): Details left/right movement	1/07/2019	LET
+GRAPH/5	Graphical pages GRAPH: Overview Luminoscope system (4/4): Details up/down movement	1/07/2019	LET
+GRAPH/6	Graphical pages GRAPH: Compact power supply panel +A1: Exterior layout & component description (1/2)	1/07/2019	LET
+GRAPH/7	Graphical pages GRAPH: Compact power supply panel +A1: Exterior layout & component description (2/2)	1/07/2019	LET
+GRAPH/8	Graphical pages GRAPH: Compact power supply panel +A1: Interior layout & component description	1/07/2019	LET
+GRAPH/9	Graphical pages GRAPH: Layout connectorbox trolley unit Luminoscope system +A10	1/07/2019	LET
+GRAPH/10	Graphical pages GRAPH: Layout optical block Luminoscope system +A12 (1/2)	1/07/2019	LET
+GRAPH/11	Graphical pages GRAPH: Layout optical block Luminoscope system +A12 (2/2)	1/07/2019	LET
+GRAPH/12	Graphical pages GRAPH: Layout APS controller board Luminoscope system +A14-1A2	1/07/2019	LET
+A1/1	Electrical panel LET +A1: arrival 230Vac power supply from Nissan South Africa, main switch & main circuit breaker	1/07/2019	LET
+A1/2	Electrical panel LET +A1: distribution 230Vac power supply	20/06/2019	LET
+A1/3	Electrical panel LET +A1: service power socket	20/06/2019	LET
+A1/4	Electrical panel LET +A1: 24Vdc power unit & distribution 24Vdc power supply	20/06/2019	LET
+A1/5	Electrical panel LET +A1: emergency stop relays & circuit	20/06/2019	LET

Table of contents

Page	Page description	Date	Edited by
+A1/6	Electrical panel LET +A1: Parallel I/O interface LET <-> wheelaligner DNH: LET inputs	1/07/2019	LET
+A1/7	Electrical panel LET +A1: Parallel I/O interface LET <-> wheelaligner DNH: LET outputs	20/06/2019	LET
+A1/8	Electrical panel LET +A1: plugs 24Vdc power supply, RS232-interface & E-stop/start interface	20/06/2019	LET
+A1/9	Electrical panel LET +A1: plugs parallel I/O interface & RS232 interface with wheelaligner DNH	20/06/2019	LET
+A10/1	Connectorbox trolley Luminoscope +A10: 24Vdc power input, distribution & supply to APS-unit + RS232 interface Luminoscope system	28/06/2019	LET
+A10/2	Connectorbox trolley Luminoscope +A10: parallel I/O interface & connections with switch 'home-position' & optical unit LVC1050	28/06/2019	LET
+A10/3	Connectorbox trolley Luminoscope +A10: wiring canbus interface & emergency stop/start interface with third party	28/06/2019	LET
+A11/1	VGA-LCD screen Luminoscope +A11: wiring 12Vdc power input & VGA-graphics input	20/06/2019	LET
+A12/1	Optical unit/light box Luminoscope +A12: plugs & wiring 24Vdc power input, RS232 interface + canbus interface	28/06/2019	LET
+A12/2	Optical unit/light box Luminoscope +A12: plugs & wiring spare 12Vdc power output + VGA graphics output	20/06/2019	LET
+A12/3	Optical unit/light box Luminoscope +A12: plugs & wiring parallel I/O interface	28/06/2019	LET
+A14/1	APS-controller board +A14 Luminoscope: plugs & wiring 24Vdc power in/out + input/output Canbus interface	28/06/2019	LET
+A14/2	APS-controller board +A14 Luminoscope: wiring motor, encoder & switches L/R movement motorized trolley Luminoscope	28/06/2019	LET
+A14/3	APS-controller board +A14 Luminoscope: wiring encoder & switches U/D movement motorized column + signaltower Luminoscope	20/06/2019	LET
+A14/4	APS-controller board +A14 Luminoscope: wiring motor with brake U/D movement motorized column Luminoscope + plug 'Hold APS' & RS232 programmation plug	20/06/2019	LET
+A14/5	APS-controller board +A14 Luminoscope: wiring emergency stop button & start button controlbox Luminoscope	28/06/2019	LET
+A14/6	APS-controller board +A14 Luminoscope: plugs input signals APS-board & connection with pushbuttons controlbox Luminoscope	20/06/2019	LET
+A14/7	APS-controller board +A14 Luminoscope: plugs output signals APS-board & connection with leds illuminated pushbuttons controlbox Luminoscope	20/06/2019	LET
+A14/8	APS-controller board +A14 Luminoscope: plug for manual up/down pushbuttons controlbox + spare plug for conection height detection bar	24/06/2019	LET
+TERM/1	TERM: Terminal strip summary	20/06/2019	LET
+TERM/2	TERM: Terminal strip connection diagram	20/06/2019	LET
+TERM/3	TERM: Terminal strip connection diagram	20/06/2019	LET
+TERM/4	TERM: Terminal strip connection diagram	20/06/2019	LET
+TERM/5	TERM: Terminal strip connection diagram	20/06/2019	LET
+TERM/6	TERM: Terminal strip connection diagram	20/06/2019	LET
+TERM/7	TERM: Terminal strip connection diagram	20/06/2019	LET
+PLUG/1	TERM: Connector strip summary	20/06/2019	LET
+PLUG/1.a	TERM: Connector strip summary	20/06/2019	LET
+PLUG/2	TERM: Connector strip connection diagram	20/06/2019	LET
+PLUG/3	TERM: Connector strip connection diagram	20/06/2019	LET
+PLUG/4	TERM: Connector strip connection diagram	20/06/2019	LET
+PLUG/5	TERM: Connector strip connection diagram	20/06/2019	LET
+PLUG/6	TERM: Connector strip connection diagram	20/06/2019	LET

Table of contents

Page	Page description	Date	Edited by
+PLUG/7	TERM: Connector strip connection diagram	20/06/2019	LET
+PLUG/8	TERM: Connector strip connection diagram	20/06/2019	LET
+PLUG/9	TERM: Connector strip connection diagram	20/06/2019	LET
+PLUG/10	TERM: Connector strip connection diagram	20/06/2019	LET
+PLUG/11	TERM: Connector strip connection diagram	20/06/2019	LET
+PLUG/12	TERM: Connector strip connection diagram	20/06/2019	LET
+PLUG/13	TERM: Connector strip connection diagram	20/06/2019	LET
+PLUG/14	TERM: Connector strip connection diagram	20/06/2019	LET
+PLUG/15	TERM: Connector strip connection diagram	20/06/2019	LET
+PLUG/16	TERM: Connector strip connection diagram	20/06/2019	LET
+PLUG/17	TERM: Connector strip connection diagram	20/06/2019	LET
+PLUG/18	TERM: Connector strip connection diagram	20/06/2019	LET
+PLUG/19	TERM: Connector strip connection diagram	20/06/2019	LET
+PLUG/20	TERM: Connector strip connection diagram	20/06/2019	LET
+PLUG/21	TERM: Connector strip connection diagram	20/06/2019	LET
+PLUG/22	TERM: Connector strip connection diagram	20/06/2019	LET
+PLUG/23	TERM: Connector strip connection diagram	20/06/2019	LET
+PLUG/24	TERM: Connector strip connection diagram	20/06/2019	LET
+PLUG/25	TERM: Connector strip connection diagram	20/06/2019	LET
+PLUG/26	TERM: Connector strip connection diagram	20/06/2019	LET
+PLUG/27	TERM: Connector strip connection diagram	20/06/2019	LET
+PLUG/28	TERM: Connector strip connection diagram	20/06/2019	LET
+PLUG/29	TERM: Connector strip connection diagram	20/06/2019	LET
+PLUG/30	TERM: Connector strip connection diagram	20/06/2019	LET
+PLUG/31	TERM: Connector strip connection diagram	20/06/2019	LET
+PLUG/32	TERM: Connector strip connection diagram	20/06/2019	LET
+PLUG/33	TERM: Connector strip connection diagram	20/06/2019	LET
+PLUG/34	TERM: Connector strip connection diagram	20/06/2019	LET
+PLUG/35	TERM: Connector strip connection diagram	20/06/2019	LET
+PLUG/36	TERM: Connector strip connection diagram	20/06/2019	LET
+PLUG/37	TERM: Connector strip connection diagram	20/06/2019	LET
+PLUG/38	TERM: Connector strip connection diagram	20/06/2019	LET
+PLUG/39	TERM: Connector strip connection diagram	20/06/2019	LET

3.a

3.c

3.b

3.c

IDENTIFICATION SYSTEMS

COMPONENT/DEVICE IDENTIFICATION SYSTEM

DRAWING NUMBER

XXXXXXXXXX

LET-PROJECTNUMBER

=

LOCATION

+A14

APS UNIT

+

BMK (PAGE/PAD)

-14S3

SWITCH UNIT DRAWN
ON PAGE 14/PATH 3

CABLE IDENTIFICATION SYSTEM

W=A10-XS100/A14-XS100.1

BMK (COMPONENT CODE) FOR CABLES

STRUCTURAL LOCATION AND DEVICE CODE INITIAL START OF CABLE

STRUCTURAL LOCATION AND DEVICE CODE ARRIVAL OF CABLE

TERMINALSTRIP IDENTIFICATION SYSTEM

+A1-XL1

STRUCTURAL LOCATION CODE FROM THE TERMINAL STRIP

BMK (COMPONENT) FOR TERMINAL STRIPS

SEQUENTIAL NUMBER

EPLAN CROSS-REFERENCE IDENTIFICATION QSYSTEM

POWER WIRING

+A1-230 L1 . 1

STRCUTURAL LOCATION CODE

VOLTAGE (400VAC,230VAC,24VAC, 24VDC)

SEQUENTIAL NUMBER

SUB-SEQUENTIAL NUMBER


CONTROL WIRING


+A1-XS100. 2: 1

ALL REFERENCES
FROM PIN/TERMINAL NUMBER
TO PIN/TERMINAL NUMBER

4

6




			Date	19/06/2019	IDE190007		Information INF: Explanation identification systems	Drawingnumber customer IDE190007	=		
			Ed.	LET	Luminoscope headlamp aiming system				+ INF		
			Appr		LVC1050-APS-TM (PLM-TM)					Page	5
Modification	Date	Name	Original						Total	145	

0	1	2	3	4	5	6	7	8	9	11	12	13	14	15	16	17	18	19
<div><div>IDENTIFICATION SYSTEMS</div><div><div>MARKING DEVICES</div><div>COMPONENT : 1x SELF-ADHESIVE LABEL LOCATED ABOVE THE COMPONENT PHOENIX CONTACT TYPE EMLP (20X8)</div><div>TERMINAL STRIPS : GROUP MARKER CARRIER FOR SNAPPING INTO END STOPS PHOENIX CONTACT TYPE KLM +LABELING INSERT MARKER PHOENIX CONTACT TYPE US-EMP (25x6MM)</div><div>TERMINALS : MARKER FOR TERMINAL BLOCKS PHOENIX CONTACT TYPE UCT-TM 5</div><div>CABLES : MARKED AT BOTH ENDS WITH PLASTIC CABLE MARKER PHOENIX CONTACT TYPE KMK2 +LABELING INSERT MARKER PHOENIX CONTACT TYPE US-EMP (29x8MM)</div><div>WIRING/CABELCORE : FOR CABLEHOLDER PHOENIX CONTACT TYPE PATG WITH TARGET MARKING (PLACE OF INSTALLATION + BMK) LABELING INSERT MARKER PHOENIX CONTACT TYPE US-WMT (23x4MM) CONDUCTOR MARKER CARRIER PHOENIX CONTACT TYPE PATG 1/23 : WIRE SECTION 1,5-2,5MM CONDUCTOR MARKER CARRIER PHOENIX CONTACT TYPE PATG 2/23 : WIRE SECTION 2-4MM</div></div></div>																		
5																		7
			Date	19/06/2019	IDE190007 Luminoscope headlamp aiming system LVC1050-APS-TM (PLM-TM)		Information INF: Marking & labeling	Drawingnumber customer IDE190007	=									
			Ed.	LET					+ INF									
			Appr							Page6								
Modification	Date	Name	Original							Total145								

WIRE COLORS IN ENCLOSURES			
DESCRIPTION CIRCUIT	POTENTIAL	WIRE COLOR	WIRE SECTION
PRIMARY CIRCUITS 400/220VAC	L1/L2/L3	BLACK	MIN. 1.5mm²
NEUTRAL WIRE	N	LIGHT BLUE	MIN. 1mm²
EQUIPMENT GROUNDING CONDUCTOR	PE	GREEN/YELLOW	MIN. 1mm²
CONTROL CIRCUITS	230 VAC	RED	MIN. 1mm²
CONTROL CIRCUITS	24VAC	RED	MIN. 1mm²
CONTROL CIRCUITS	0 VAC	RED	MIN. 1mm²
CIRCUITS UPSTREAM DISCONNECT SWITCH	L1/L2/L3	ORANGE	MIN. 1.5mm²
CONTROL CIRCUITS	24VDC	DARK BLUE	MIN. 1mm²
CONTROL CIRCUITS	0 VDC	DARK BLUE	MIN. 1mm²
INTERLOCK CIRCUITS	-	ORANGE	MIN. 1mm²

COLORS ABBREVIATIONS			
COLOR ABBREVIATION	COLOR	COLOR ABBREVIATION	COLOR
BN	BROWN	VI	VIOLETT
RD	RED	GY	GRAY
PK	PINK	WH	WHITE
YE	YELLOW	BK	BLACK
GN	GREEN	GNYE	GREEN/YELLOW
BU	BLUE	TQ/LIGHT BU	LIGHT BLUE
OG	ORANGE	DARK BU	DARK BLUE


TERMINAL SIZES		
DESCRIPTION CIRCUIT	POTENTIAL	WIRE COLOR
PRIMARY POWER CIRCUITS 400VAC	L1/L2/L3/N	0.08-2.5mm²-TERMINALS Phoenix Contact ST-Series GREY
GROUNDING PRIMARY POWER CIRCUITS 400/220VAC	PE	0.08-2.5mm²-TERMINALS Phoenix Contact ST-Series GREEN-YELLOW
POWER CIRCUITS UPSTREAM DISCONNECT SWITCH	L1/L2/L3/N	0.08-2.5mm²-TERMINALS Phoenix Contact ST-Series GREY
CONTROL CIRCUITS	230 VAC	0.08-2.5mm²-TERMINALS Phoenix Contact ST-Series GREY
CONTROL CIRCUITS	24 VAC	0.08-2.5mm²-TERMINALS Phoenix Contact ST-Series GREY
CONTROL CIRCUITS	0 VAC	0.08-2.5mm²-TERMINALS Phoenix Contact ST-Series GREY
CONTROL CIRCUITS	24 VDC	0.08-2.5mm²-TERMINALS Phoenix Contact ST-Series GREY
CONTROL CIRCUITS	0 VDC	0.08-2.5mm²-TERMINALS Phoenix Contact ST-Series GREY
GROUNDING PRIMARY CONTROL CIRCUITS	PE	0.08-2.5mm²-TERMINALS Phoenix Contact ST-Series GREEN-YELLOW
INTERLOCK CIRCUITS	L1/L2/L3	0.08-2.5mm²-TERMINALS Phoenix Contact ST-Series ORANGE

0	1	2	3	4	5	6	7	8	9	11	12	13	14	15	16	17	18	19																																																																								
<div>BMK (COMPONENT IDENTIFICATION) / LOCATION<div>(The components in the enclosures will be marked with LUTZE CS1)</div></div>																																																																																										
<table><tr><th>PURPOSE OF COMPONENT</th><th>IDENTIFICATION CHARACTER</th><th>EXAMPLE</th></tr><tr><td>FUNCTIONAL ELEMENTS</td><td>A</td><td>PANELS, BOXES, KEYBOARDS, MOUSE, COMPUTER</td></tr><tr><td>ELECTRIC AND NON-ELECTRIC LEVEL CONVERTERS</td><td>B</td><td>ENCODER, SENSORS</td></tr><tr><td>CAPACITORS</td><td>C</td><td>PHOTO-ELECTRIC CEL</td></tr><tr><td>BINARY ELEMENTS</td><td>D</td><td>/</td></tr><tr><td>LIGHTING FIXTURES</td><td>E</td><td>HEATER, CABINET ILLUMINATION</td></tr><tr><td>PROTECTION DEVICES/FUSES</td><td>F</td><td>FUSES, CIRCUIT BREAKER</td></tr><tr><td>POWER SOURCES</td><td>G</td><td>BATTERY, POWER SUPPLY UNIT</td></tr><tr><td>SIGNALISATIONS</td><td>H</td><td>SIGNAL LAMP, LED, ACOUSTICAL SIGNAL DEVICE</td></tr><tr><td>RELAY DEVICES</td><td>K</td><td>RELAY, CONTACTOR RELAY</td></tr><tr><td>INDUCTORS/COILS</td><td>L</td><td>SPOOL</td></tr><tr><td>MOTORS</td><td>M</td><td>LINEAR MOTOR, DC-MOTOR, AC-MOTOR</td></tr><tr><td>REGULATING DEVICES</td><td>N</td><td>/</td></tr><tr><td>MEASUREMENT INSTRUMENTS</td><td>P</td><td>VOLT METER, WATT METER</td></tr><tr><td>DISCONNECT DEVICES</td><td>Q</td><td>MAIN SWITCH, FUSED DISCONNECTOR</td></tr><tr><td>RESISTORS</td><td>R</td><td>SHUNT, RESISTOR</td></tr><tr><td>SWITCHES</td><td>S</td><td>PUSHBUTTON, SELECTOR SWITCH</td></tr><tr><td>TRANSFORMERS</td><td>T</td><td>POWER TRANSFORMER, MEASURING TRANSFORMER</td></tr><tr><td>FREQUENCY CONVERTOR</td><td>U</td><td>DEMODULATOR, FREQUENCY CONVERTOR</td></tr><tr><td>RECTIFIERS/DIODES</td><td>V</td><td>DIODE, TRANSISTOR</td></tr><tr><td>CONDUCTING DEVICES</td><td>W</td><td>CABLE, CONDUCTOR</td></tr><tr><td>TERMINALS, CONNECTORS</td><td>X</td><td>CONNECTOR, PLUG CONNECTOR TEMRINAL STRIPS</td></tr><tr><td>MECHANICAL DEVICES</td><td>Y</td><td>VALVE, PLUG CONNECTOR TERMINAL STRIPS</td></tr><tr><td>FILTERS & SUPRESSORS</td><td>Z</td><td>/</td></tr></table>																			PURPOSE OF COMPONENT	IDENTIFICATION CHARACTER	EXAMPLE	FUNCTIONAL ELEMENTS	A	PANELS, BOXES, KEYBOARDS, MOUSE, COMPUTER	ELECTRIC AND NON-ELECTRIC LEVEL CONVERTERS	B	ENCODER, SENSORS	CAPACITORS	C	PHOTO-ELECTRIC CEL	BINARY ELEMENTS	D	/	LIGHTING FIXTURES	E	HEATER, CABINET ILLUMINATION	PROTECTION DEVICES/FUSES	F	FUSES, CIRCUIT BREAKER	POWER SOURCES	G	BATTERY, POWER SUPPLY UNIT	SIGNALISATIONS	H	SIGNAL LAMP, LED, ACOUSTICAL SIGNAL DEVICE	RELAY DEVICES	K	RELAY, CONTACTOR RELAY	INDUCTORS/COILS	L	SPOOL	MOTORS	M	LINEAR MOTOR, DC-MOTOR, AC-MOTOR	REGULATING DEVICES	N	/	MEASUREMENT INSTRUMENTS	P	VOLT METER, WATT METER	DISCONNECT DEVICES	Q	MAIN SWITCH, FUSED DISCONNECTOR	RESISTORS	R	SHUNT, RESISTOR	SWITCHES	S	PUSHBUTTON, SELECTOR SWITCH	TRANSFORMERS	T	POWER TRANSFORMER, MEASURING TRANSFORMER	FREQUENCY CONVERTOR	U	DEMODULATOR, FREQUENCY CONVERTOR	RECTIFIERS/DIODES	V	DIODE, TRANSISTOR	CONDUCTING DEVICES	W	CABLE, CONDUCTOR	TERMINALS, CONNECTORS	X	CONNECTOR, PLUG CONNECTOR TEMRINAL STRIPS	MECHANICAL DEVICES	Y	VALVE, PLUG CONNECTOR TERMINAL STRIPS	FILTERS & SUPRESSORS	Z	/
PURPOSE OF COMPONENT	IDENTIFICATION CHARACTER	EXAMPLE																																																																																								
FUNCTIONAL ELEMENTS	A	PANELS, BOXES, KEYBOARDS, MOUSE, COMPUTER																																																																																								
ELECTRIC AND NON-ELECTRIC LEVEL CONVERTERS	B	ENCODER, SENSORS																																																																																								
CAPACITORS	C	PHOTO-ELECTRIC CEL																																																																																								
BINARY ELEMENTS	D	/																																																																																								
LIGHTING FIXTURES	E	HEATER, CABINET ILLUMINATION																																																																																								
PROTECTION DEVICES/FUSES	F	FUSES, CIRCUIT BREAKER																																																																																								
POWER SOURCES	G	BATTERY, POWER SUPPLY UNIT																																																																																								
SIGNALISATIONS	H	SIGNAL LAMP, LED, ACOUSTICAL SIGNAL DEVICE																																																																																								
RELAY DEVICES	K	RELAY, CONTACTOR RELAY																																																																																								
INDUCTORS/COILS	L	SPOOL																																																																																								
MOTORS	M	LINEAR MOTOR, DC-MOTOR, AC-MOTOR																																																																																								
REGULATING DEVICES	N	/																																																																																								
MEASUREMENT INSTRUMENTS	P	VOLT METER, WATT METER																																																																																								
DISCONNECT DEVICES	Q	MAIN SWITCH, FUSED DISCONNECTOR																																																																																								
RESISTORS	R	SHUNT, RESISTOR																																																																																								
SWITCHES	S	PUSHBUTTON, SELECTOR SWITCH																																																																																								
TRANSFORMERS	T	POWER TRANSFORMER, MEASURING TRANSFORMER																																																																																								
FREQUENCY CONVERTOR	U	DEMODULATOR, FREQUENCY CONVERTOR																																																																																								
RECTIFIERS/DIODES	V	DIODE, TRANSISTOR																																																																																								
CONDUCTING DEVICES	W	CABLE, CONDUCTOR																																																																																								
TERMINALS, CONNECTORS	X	CONNECTOR, PLUG CONNECTOR TEMRINAL STRIPS																																																																																								
MECHANICAL DEVICES	Y	VALVE, PLUG CONNECTOR TERMINAL STRIPS																																																																																								
FILTERS & SUPRESSORS	Z	/																																																																																								
810																																																																																										
<table><tr><td></td><td></td><td></td><td>Date</td><td>19/06/2019</td><td>IDE190007</td><td rowspan="4"></td><td rowspan="4">Information INF: Explanation BMK/Component identification</td><td rowspan="4">Drawingnumber customer IDE190007</td><td colspan="2">=</td></tr><tr><td></td><td></td><td></td><td>Ed.</td><td>LET</td><td>Luminoscope headlamp aiming system</td><td colspan="2">+ INF</td></tr><tr><td></td><td></td><td></td><td>Appr</td><td></td><td>LVC1050-APS-TM (PLM-TM)</td><td colspan="2"></td></tr><tr><td>Modification</td><td>Date</td><td>Name</td><td>Original</td><td></td><td></td><td></td><td>Page Total</td><td>9 145</td></tr></table>																						Date	19/06/2019	IDE190007		Information INF: Explanation BMK/Component identification	Drawingnumber customer IDE190007	=					Ed.	LET	Luminoscope headlamp aiming system	+ INF					Appr		LVC1050-APS-TM (PLM-TM)			Modification	Date	Name	Original				Page Total	9 145																																				
			Date	19/06/2019	IDE190007		Information INF: Explanation BMK/Component identification	Drawingnumber customer IDE190007	=																																																																																	
			Ed.	LET	Luminoscope headlamp aiming system				+ INF																																																																																	
			Appr		LVC1050-APS-TM (PLM-TM)																																																																																					
Modification	Date	Name	Original							Page Total	9 145																																																																															

BMK (COMPONENT IDENTIFICATION) / LOCATION

For an unique identification; the following elements are forseen from a sub-characater

CHARACTER	ADD-ON	PURPOSE OF COMPONENT
S		SWITCH (GENERAL)
S	E	PROXIMITY SWITCH
S	D	MECHANICAL ACTIVATED SWITCH
S	L	ILLUMINATED SWITCH
S	N	EMERGENCY STOP SWITCH
S	P	PROGRAMMABLE SWITCH
S	W	SELECTORSWITCH
X		CONNECTION DEVICE (GENERAL)
X	L	TERMINAL STRIP
X	S	CONNECTION PLUG





POWER SUPPLY & CONTROL PANEL +A1
FOR HEADLIGHT AIMING SYSTEM LUMINOSCOPE
TYPE LVC1050-APS-TM


HEADLIGHT AIMING SYSTEM LUMINOSCOPE
TYPE LVC1050-APS-TM (IN 'HOME-POSITION')


+INF/12

2


			Date	1/07/2019	IDE190007 Luminoscope headlamp aiming system LVC1050-APS-TM (PLM-TM)		VAARTLAAN 20 B-9800 DEINZE TEL:+32 (0)9 381 87 87 FAX:+32 (0)9 386 92 00 EMAIL:INFO@LET.BE	Graphical pages GRAPH: General installation overview	Drawingnumber IDE190007	+ GRAPH						
			Ed.	LET												
			Appr													
Modification	Date	Name	Original													
										<table><tr><td></td><td>Page</td><td>1</td></tr><tr><td>Total</td><td></td><td>145</td></tr></table>		Page	1	Total		145
	Page	1														
Total		145														













LEGEND

- 1 : +A1-1S10 = MAIN POWER CUTOUT SWITCH
2 : +A1-1H7 = INDICATOR LIGHT 230VAC POWER OK
3 : +A1-4H2 = INDICATOR LIGHT 24VDC POWER SUPPLY OK



LEGEND

- 1 : CABLE GLAND FOR CABLE WITH THE 1~230VAC+PE POWER INPUT FROM POWER NET NISSAN SOUTH-AFRICA OR ELECTRICAL PANEL DNH MANUFACTURING
- 2 : CABLE GLAND FOR CABLE PARALLEL I/O INTERFACE LET WITH DNH MANUFACTURING
- 3 : +A1-XS100 = PLUG 24VDC POWER SUPPLY -> LUMINOSCOPE SYSTEM
- 4 : +A1-XS101.3 = PLUG RS232 INTERFACE WITH OPTICAL UNIT FROM LUMINOSCOPE SYSTEM
- 5 : +A1-XS103.3 = PLUG PARALLEL I/O INTERFACE WITH OPTICAL UNIT FROM LUMINOSCOPE SYSTEM
- 6 : +A1-XS104.3 = PLUG E-STOP & START INTERFACE WITH LUMINOSCOPE SYSTEM
- 7 : +A1-XS101.4 = PLUG RS232 INTERFACE WITH PC-CONFIGURATION DNH MANUFACTURING




LEGEND

- 1 : +A10-XS100.2 = PLUG 24VDC POWER INPUT FROM POWER SUPPLY PANEL
- 2 : +A10-XS102.2 = PLUG OUTPUT CANBUS INTERFACE LUMINOSCOPE SYSTEM (CAN-RESISTOR)
- 3 : +A10-XS104.2 : PLUG E-STOP/START INTERFACE LUMINOSCOPE SYSTEM <-> POWER SUPPLY PANEL
- 4 : +A10-XS101.2 = PLUG OUTPUT RS232-INTERFACE LUMINOSCOPE SYSTEM <-> POWER SUPPLY PANEL
- 5 : +A10-XS103.2 = PLUG PARALLEL I/O INTERFACE LUMINOSCOPE SYSTEM <-> POWER SUPPLY PANEL
- 6 : +A10-XL1 = TERMINALS 24VDC DISTRIBUTION FOR APS UNIT & SCREWDRIVERS LUMINOSCOPE SYSTEM

LEGEND

- 7 : +A10-XS117.1 = PLUG FOR CONNECTION SWITCH 'HOME-POSITION' LUMINOSCOPE
- 8 : +A10-XS102.1 = PLUG INPUT CANBUS INTERFACE FROM OPTICAL UNIT LUMINOSCOPE SYSTEM
- 9 : +A10-XS110 = SPARE PLUG 24VDC POWER SUPPLY -> SCREWDRIVER CONTROLLER CANDIS LUMINOSCOPE SYSTEM
- 10 : +A10-XS100.3 = PLUG 24VDC OUTPUT -> APS CONTROLLER BOARD LUMINOSCOPE SYSTEM
- 11 : +A10-XS104.1 : PLUG E-STOP/START CIRCUIT WITH CONTROLBOX APS-ENCLOSURE LUMINOSCOPE SYSTEM
- 12 : +A10-XS103.1 = PLUG PARALLEL I/O INTERFACE <-> OPTICAL UNIT LUMINOSCOPE SYSTEM
- 13 : +A10-XS101.1 = PLUG RS232-INTERFACE <-> OPTICAL UNIT LUMINOSCOPE SYSTEM



LEGEND

- 1 : ON-OFF BUTTON.
- 2 : +A12-XS100.3 = PLUG 24VDC POWER INPUT FROM APS CONTROLLER BOARD
- 3 : +A12-XS102 = PLUG CANBUS OUTPUT -> APS CONTROLLER BOARD
- 4 : +A12-XS101 = PLUG RS232 INTERFACE -> CONNECTORBOX TROLLEY
- 5 : +A12-XS104 = PLUG 12VDC POWER OUTPUT -> LCD SCREEN POSITIONING MAST
- 6 : +A12-XS105 = PLUG VGA OUTPUT -> LCD SCREEN POSITIONING MAST
- 7 : +A12-XS103 = PLUG PARALLEL I/O INTERFACE <-> CONNECTORBOX TROLLEY

			Date	1/07/2019
			Ed.	LET
			Appr	
Modification	Date	Name	Original	

IDE190007
Luminoscope headlamp aiming system
LVC1050-APS-TM (PLM-TM)





VAARTLAAN 20
B-9800 DEINZE
TEL: +32 (0)9 381 87 87
FAX: +32 (0)9 386 92 00
EMAIL: INFO@LET.BE

Graphical pages GRAPH: Layout optical block Luminoscope system +A12 (2/2)
--


Drawingnumber IDE190007

+ GRAPH	
	Page 11
Total	145





1	2	3	4	5	6	7	8	9	10	12	13	14	15	16	17	18	19	20
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----



230VAC POWER SUPPLY
LUMINOSCOPE SYSTEM


230VAC POWER SUPPLY
SERVICE POWER SOCKET

SPARE TERMINALS
230VAC POWER SUPPLY

SPARE TERMINALS
230VAC POWER SUPPLY


PE-WIRING

1										3		
			Date	20/06/2019	IDE190007		VAARTLAAN 20 B-9800 DEINZE TEL: +32 (0)9 381 87 87 FAX: +32 (0)9 386 92 00 EMAIL: INFO@LET.BE	Electrical panel LET +A1: distribution 230Vac power supply	Drawingnumber IDE190007	+ A1		
			Ed.	LET	Luminoscope headlamp aiming system						Page	2
			Appr		LVC1050-APS-TM (PLM-TM)						Total	145
Modification	Date	Name	Original									







1	2	3	4	5	6	7	8	9	10	12	13	14	15	16	17	18	19	20
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----




CONNECTION WITH POWER SUPPLY PANEL +A1



CONNECTION WITH POWER SUPPLY PANEL +A1



CONNECTION 'PARK SWITCH' TROLLEY



W=A12-XS103/A10-XS103.1
UNITRONIC® FD CP plus
3,4 m
25x0,25 mm²
Cable Parallel I/O interface
optical unit LVC1050 <-> connectorbox
Luminoscope unit
HFKAB 191214_01KOL

+A10-XS117.1
+A14/2.18

5117.1:3

+A12/3.9

PARALLEL I/O INTERFACE <-> OPTICAL UNIT +A12

VAARTLAAN 20
B-9800 DEINZE
TEL:+32 (0)9 381 87 87
FAX:+32 (0)9 386 92 00
EMAIL:INFO@LET.BE


Connectorbox trolley Luminoscope +A10:
parallel I/O interface & connections with
switch 'home-position' & optical unit LVC1050

Drawingnumber
IDE190007

+ A10

Page	2
Total	145





W=A12-XS104/A11-XS104.1

ÖLFLEX® FD CLASSIC 810
2,52 m
2x0,75 mm²
Cable VGA output
optical unit LVC1050 -> LCD ssreen
Luminoscope unit
HFKAB 080252A00KOL

W=A12-XS105/A11-XS105.1

KABAS VGA-03,0-MM
2,57 m
10x0.25 mm²
Cable VGA output
optical unit LVC1050 -> LCD ssreen
Luminoscope unit
HFKAB 080253_00KOL

+A12-XS104
+A12/2.5

+A12-XS105
+A12/2.11

12VDC POWER INPUT FROM OPTICAL UNIT +A12

VGA INPUT FROM OPTICAL UNIT +A12






1	2	3	4	5	6	7	8	9	10	12	13	14	15	16	17	18	19	20
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----


+A14
/2.2 /4.1 /6.1 /8.1
/3.1 /5.1 /7.1
APS XZ-MOVEMENT LUMINOSCOPE

-1A2
/2.2 /4.1 /6.1 /8.1
/3.1 /5.1 /7.1
APS CONTROLLER BOARD
090338C


POWER INPUT
APS CONTROLLER BOARD




POWER OUT
APS CONTROLLER BOARD




CANBUS INPUT
APS CONTROLLER BOARD




CANBUS OUTPUT
APS CONTROLLER BOARD




W=A10-XS100.2/A14-1A2-PL5
ÖLFLEX® CLASSIC 100
1,39 m
3x0,75 mm²
Cable 24Vdc connectorbox -> APS controller board
Luminoscope unit
HFKAB 191210_01KOL




W=A14-1A2-PL4/A12-XS100.3
ÖLFLEX® FD CLASSIC 810
2,38 m
2x0,75 mm²
Cable 24Vdc APS controller board ->
optical unit LVC1050 Luminoscope unit
HFKAB 080254_00KOL



W=A12-XS102/A14-1A2-PL7
KABUT 4P-PLATTEKABEL-RJ10
2,41 m
4x0,14 mm²
Cable canbus input APS-board from
optical unit LVC1050 Luminoscope unit
HFKAB 080256_00KOL



W=A14-1A2-PL8/A10-XS102.1
KABUT 4P-PLATTEKABEL-RJ10
1,5 m
4x0,14 mm²
Cable canbus output APS board ->
connectorbox trolley Luminoscope unit
HFKAB 191180_01KOL



24Vdc POWER INPUT
FROM CONNECTORBOX +A10

24Vdc POWER ->
OPTICAL BLOCK +A12

CANBUS INPUT FROM
OPTICAL BLOCK +A12

CANBUS OUTPUT ->
CONNECTORBOX +A10

+A12/3

2

			Date	28/06/2019	IDE190007		VAARTLAAN 20 B-9800 DEINZE TEL: +32 (0)9 381 87 87 FAX: +32 (0)9 386 92 00 EMAIL: INFO@LET.BE	APS-controller board +A14 Luminoscope: plugs & wiring 24Vdc power in/out + input/output Canbus interface	Drawingnumber IDE190007	+ A14					
			Ed.	LET	Luminoscope headlamp aiming system										
			Appr		LVC1050-APS-TM (PLM-TM)										
Modification	Date	Name	Original								<table><tr><td>Page</td><td>1</td></tr><tr><td>Total</td><td>145</td></tr></table>	Page	1	Total	145
Page	1														
Total	145														



